




Makita DT01 LED light replacment

This guide walks through the steps required to replace the LED light on Makita DT01 12V max Lithium-Ion Cordless Impact Driver.

Written By: Ya'Rub Al Manwari



INTRODUCTION

This guide walks through the steps required to replace the LED light on Makita DT0112V max Lithium-Ion Cordless Impact Driver.



TOOLS:


- [JIS Driver Set](#) (1)
 - [Tweezers](#) (1)
-

Step 1 — LED light




- Take out the battery.
- Unscrew the six screws in the top of the drill.

Step 2



- Motor and trigger should be separated.
- The LED cable should be taken out from the trigger.

Step 3



- Take out the plastic tape that is stacked on the LED light.
- Take out the two cables that are connecting with the LED light.
- Reconnect the two cables again with the new LED light.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-17 12:27:06 AM.